

STEP 4

For Footlocker Installation

Simply drill and secure the foot lockers to the floor where the two back feet of the bath will be positioned on installation. The back feet of the bath are the two feet opposite to where you would normally enter the bath from. Refer Figure 5. Please consider compliance with local authority water proofing regulations when installing footlockers.




Figure 4
Footlocker




Figure 5

Freestanding Bath with Footlockers


STEP 5

For Smart Waste Installation

Position bath on the floor marking as marked on step 2 and apply silicone around the base surrounding of the bath, as illustrated in Figure 7.


For Flexible Connector Installation

Slide the bath into position for the back feet to glide under and into the footlockers. Refer to Figure 6. Make sure that flexible connector is not kinked upward on installation, as this will result in drainage issue. Apply silicon around the base surrounding of the bath, as illustrated in Figure 7.



Top View

Figure 6



Side View

Foot installation to footlocker




Figure 7

STEP 6

Silicon applied around base surrounding of bath. Rest the bath for a minimum 24 hours to let the silicon fully cure.

In Australia

For more information call 13 14 16
or go to www.clark.com.au

* For full warranty terms and conditions,
please visit www.clark.com.au

In New Zealand

For more information call 09 279 2700

* For full warranty terms and conditions,
please visit www.clark.com.au

C L Δ R K

Freestanding Bath

Care & Installation Guide

This manual has to be left with the end user

WARNING:

Before commencing installation, please read these instructions carefully. Installation must comply with all State By-Laws and any requirements imposed by local authorities.

Congratulations on the purchase of your new Clark Freestanding bath. We are sure you will have many years of relaxation, turning your bathroom into a stylish retreat.

CLARK ACRYLIC FREESTANDING BATHS

All our products are made from sanitaryware grade acrylic. It resists chipping, will not rust and has excellent heat retention properties. Its high gloss finish has natural slip resistance.

All dimensions are in millimeters and are subject to normal manufacturing variations. Therefore, Clark reserves the right to vary specifications without notice.

CLEANING YOUR BATH

- To preserve the polished surface, after using your bath, clean with soft cloth and warm soapy water to wash away any body oils or soap residue that forms a ring tide mark.
- As a weekly cleaner we recommend warm, soapy water. Do not use powders, pastes, cream cleansers, thinners, window cleaning sprays or dry cleaning liquid, etc.
- Stubborn marks or fine scratches may be polished out with Brasso.
- When coloured essential oils are used, first test that the colour won't stain your bath. Always add oils into a bath full of water. Never pour them into an empty bath.

THINGS TO REMEMBER

- Compliance with AS.3740 Waterproofing of wet areas within residential buildings applies when installing baths.
- Water test the bath prior to enclosing to ensure it drains correctly as no claims for non-draining baths will be valid after enclosing or tiling has been done.
- All materials to comply with appropriate Australian & NZ Standards.
- Installation must comply with appropriate building codes and local authority requirements.

WARNING

BEFORE COMMENCING INSTALLATION, PLEASE READ THESE INSTRUCTIONS CAREFULLY. INSTALLATION MUST COMPLY WITH ALL STATE BY-LAWS AND ANY REQUIREMENTS IMPOSED BY THE LOCAL AUTHORITIES

WARNING

NO PUTTIES OR SILICONES CONTAINING LINSEED OIL ARE TO BE USED AS SEALANTS ON THE WASTE. WE RECOMMEND SANITARYWARE GRADE SILICONE.

RECEIVING YOUR BATH

- Unpack and check for damage. After receiving your bath, please unpack and check carefully for any damage. Repack the bath if it is not being immediately installed. Clark reserves the right to reject any claim for damage if not notified in a timely manner.
- Protect your bath. Before commencing installation, ensure the bath is completely protected, leave protection film in place until the bathroom is complete. Scratches, cracks and chips incurred during installation are not covered by the warranty.

TOOLS REQUIRED FOR INSTALLATION



Drill



Drill Bit

Drill & Drill Bit required for flexible connector installation



Marking Pencil




Tape Measure

NOTE:

Freestanding bath is not designed to take weight on the rim. Do not sit or stand on the bath rim.

STEP 1

Adjust the bath feet until the bath tub base is 3mm above the floor. This can be done by turning the feet bolts accordingly.



STEP 2

Mark the floor with the outline of the bath, at the final installation position with the marking pencil.

Step 3

Carefully tilt bath on its side and use Iplex smart waste or flexible connector to connect waste outlet to the trap, as illustrated on Figure 2 and 3.

Be sure to protect the bath surface. Damage during installation is not covered by warranty.

Installation must comply with appropriate building codes and local authority requirements.




Figure 2

Smart Waste Installation




Figure 3

Flexible connector installation.