




Adjustment range from Nogging Face to the Tile Face is 50mm to 68mm as shown.






Remove bottom cap from rough in and apply teflon tape to thread. Re-attach cap when applied.




Place mixer assembly onto nogging ensuring it is level. Fasten onto nogging using the screws provided.





Connect water supply and water outlet.



Using Hole Template supplied mark out and drill holes in cement sheeting and tile face.









Seal waterproofing membrane up to waterproofing sleeve.

6 Use knife to trim waterproofing sleeve until flush with the tile face.






Insert Sleeve onto the cartridge, screwing on until tightened, then push the dome into the sleeve



Push dress plate onto the cartridge, ensuring it is flush with the wall, and fix Mixer Handle into position.



Insert grub screw and grub screw cap into the Mixer Handle, fastening tightly.





- Flush out all pipe work prior to installation.
- Fit the water temperature exceeds 75°C, an approved tempering valve must be fitted.
- Installation should comply with Australian standard AS3500.1 or relevant local authority requirements. Showers may not be suitable for use within:
- Gravity-fed water systems

- Some instantaneous hot water systems; or
- Pressure supply less than 150kPa; NOTE: The 500kPa maximum water supply pressure does not apply to fire service outlets.

Failure to comply with the above may void all warranties.

VARRANTY:

Please refer to the full warranty statement enclosed with the product before installing.

MAINTENANCE AND CARE:

- Chrome plated surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are
- Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.

DISCLAIME

While we aim to ensure the specifications shown are correct at the time of printing, we reserve the right to make modifications without prior notice. Always use the physical product measurements for mark-ups and roughing-in as the line drawing shown may differ from the actual product over time.

*All measurements are shown in millimeters.





recommended

150-

working pressure

500KPa

maximum hot